



# BUTTON OPERATION AND SETUP

⚠ Read all instructions before setting.  
Especially for "speed calibration", initially decide which way you will do from 3 types.




## NORMAL MODE

※ Lower display always shows current SPEED.



## SETUP MODE



## UNIT SETUP (KM/H or MPH)

At SETUP MODE, choose UNIT SETUP and hold down SET for 2 seconds.



To switch between "KM/H" and "MPH", press MODE.

Hold down SET for 2 seconds. The display goes back to NORMAL MODE.

## SPEED CALIBRATION

At SETUP MODE, choose SPEED CALIBRATION and hold down SET for 2 seconds. You can choose one way from 3 types of calibration.



### AUTO CALIBRATION MODE

When ready to drive, hold down SET for 2 seconds.

Press MODE.

Drive exactly one(1) kilometer/mile. (When driving, the display counts number of pulse obtained from sensor.)

After driving one(1) kilometer/mile, stop the vehicle and press MODE to finish the setting.

※18133 is sample.

Hold down SET for 2 seconds. The display goes back to NORMAL MODE.

### SPEED ADJUST MODE

When ready to drive, hold down SET for 2 seconds.

Start driving following another vehicle running at constant speed of 40km/h(MPH).

Press MODE in driving at actual speed 40km/h(MPH) to finish the setting.

The display will start indicating the current speed after a while and automatically goes back to NORMAL MODE.

### MANUAL MODE

Calculate the value of "pulse per km" by A + B

**A pulses per revolution**  
Enter the AUTO CALIBRATION MODE, turn the wheel exactly 10 revolutions. The display shows the pulses per 10 revolutions. Divide this value by 10.

**B tyre circumference (km)**  
Measure your tyre circumference in "cm" and divide by 100,000 to be "km".

**A ÷ B = pulses per km**

Then enter MANUAL MODE and input this value as follows.

Hold down SET for 2 seconds.

Press MODE to fix and go to the next digit setting.

Continue this operation until the last digit is input.

※18133 is sample.

Hold down SET for 2 seconds. The display goes back to NORMAL MODE.

## RPM SETUP

At SETUP MODE, choose RPM SETUP and hold down SET for 2 seconds.

### PPR (Pulse Per Rotation) SETUP

To switch between engine types, press MODE.

Select PPR from the following.

- 1P-1r: 1pulse per 1revolution
- 1P-2r: 1pulse per 2revolutions
- 2P-1r: 2pulses per 1revolution
- 30P1r: For 2000up Harley-Davidson only.

Hold down SET for 2 seconds at the intended type to set. The display goes back to NORMAL MODE.

### SHIFT UP WARNING SETUP

Press SET to modify the flashing number. (Input number 0 or 1 only)

Press SET to modify the flashing number. (Input number 0 to 9)

Continue this operation until the hundred digit is input. (Input number 0 or 5 only)

※13500 is sample.

Hold down SET for 2 seconds. The display goes back to NORMAL MODE.