

Soziusfußrasten Tieferlegungssatz

YAMAHA MT - 09

Artikel-Nr.: 700.4536 01 05 anthrazit

Seitenkoffer
Topcases
Gepäckträger
Lock it System
Softbags
Aluminiumkoffer
Lederkoffer
Schutzbügel
Hauptständer
Chopper-Parts
Accessoires



Montage

Der Bausatz umfaßt die folgenden Teile:

Stück	Bestellnr.	Bezeichnung
1	700008729	Tieferlegung links
1	700008730	Tieferlegung rechts
1	700008423	Schraubensatz, bestehend aus:
4		Inbusschrauben M8 x 30
2		Distanzplättchen
2		Sicherungssplinte ø 2mm x 25



Weiteres Zubehör lieferbar.



Hepco & Becker GmbH
An der Steinmauer 6
D-66955 Pirmasens
Tel.: 0049 6331 - 1453 - 100
www.hepco-becker.de

Anzugsmomente des Motorradherstellers beachten!
Nach der Montage alle Verschraubungen auf festen
Sitz kontrollieren!
Bitte beachten Sie unsere beigegefügte
Serviceinformationen.

Soziusfußrasten Tieferlegungssatz

YAMAHA MT - 09

Artikel-Nr.: 700.4536 01 05 anthrazit

Seitenkoffer
Topcases
Gepäckträger
Lock it System
Softbags
Aluminiumkoffer
Lederkoffer
Schutzbügel
Hauptständer
Chopper-Parts
Accessoires



Montage

Vorbereitung:

Den Bremsflüssigkeitsbehälter vom Original-Fußrastenhalter abschrauben (rechts).

Halter der Soziusrasten demontieren.

Fußraste vom Halter abbauen (Achtung - die Kugel nicht verlieren). Der Originalhalter entfällt.

Montage der Tieferlegung:

Die Fußraste mit dem original Bolzen und dem mitgelieferten Splint an die Tieferlegung montieren.

An der Unterseite das original Rastplättchen verwenden, an der Oberseite der Raste wird zusätzlich ein Distanzplättchen verbaut.

Die Fußrasten werden mit den Inbusschrauben M8 x 30mm am Rahmen verschraubt.

Den Bremsflüssigkeitsbehälter wieder anschrauben.

HINWEIS:

Kombination mit Lock it Kofferträger möglich. Dieser wird mit den Lock it Systemschrauben am Fersenschutz des Fußrastenhalters fixiert.



Passenger footrest lowering set

YAMAHA MT - 09
item.-no.: 700.4536 01 05 anthracite

Side cases
Top cases
luggage frames
Lock it system
Softbags
Aluminium luggage
Leather luggage
Protection bars
Center stands
Chopper parts
Accessories



Assembling instructions

The kit includes the following parts:

Quant	item no.	description
1	700008729	lowering left
1	700008730	lowering right
1	700008423	screw kit, contains:
4		allen screw M8 x 30
2		distance plates
2		splint \varnothing 2mm x 25



More accessories available.



Hepco & Becker GmbH
An der Steinmauer 6
D-66955 Pirmasens
Tel.: 0049 6331 - 1453 - 100
www.hepco-becker.de

Control all screw connections after the assembling for tightness!
Please notice our enclosed service information.

Passenger footrest lowering set

YAMAHA MT - 09

item.-no.: 700.4536 01 05 anthracite

Side cases
Top cases
luggage frames
Lock it system
Softbags
Aluminium luggage
Leather luggage
Protection bars
Center stands
Chopper parts
Accessories



Assembling instructions

Preparing:

Dismantle the brake fluid reservoir from the original footrest holder (right side).

Disassemble original footrest holder.

Disassemble passenger's footrest from the original footrest holder. Attention! Do not lose the ball.

Original holder is obsolete.

Fastening of the lowering:

Reassemble the original footrests using the splints.

In addition a spacer plate is installed at the top of the footrest

The footrests are screwed with allen screws M8 x 30mm on the frame.

Mount the brake fluid reservoir again.

Combination with Lock it side carrier possible. This is fixed with the Lock it screws on the heel protection of the footrest holder.

