

PORTAPACCO SPECIFICO - SPECIFIC HOLDER
 PORTE-PAQUET SPÉCIFIQUE - SPEZIFISCHER TRÄGER
 PORTA-EQUIPAJE ESPECÍFICO

YAMAHA SUPER TENERE' 1200cc 2010

ISTRUZIONI DI MONTAGGIO - MOUNTING INSTRUCTIONS
 INSTRUCTIONS DE MONTAGE - BAUANLEITUNG - INSTRUCCIONES DE MONTAJE

1



SUPPORTO
 SUPPORT
 SUPPORT
 HALTERUNG
 SOPORTE

Q.TY n.2(Dx-Sx)

2




DISTANZIALE Ø18x15mm
 Foro Ø8mm, V544

SPACER
 ENTRETÔISE
 DISTANZSTÜCK
 DISTANCIADOR

Q.TY n.4

3




VITE TEF M8x40mm

SCREW
 VIS
 SCHRAUBE
 TORNILLO

Q.TY n.4


4



PIASTRA M5
 PLATE
 PLATINE
 PLATTE
 PARRILLA

Q.TY n.1

5




VITE TCEI M6x25mm

SCREW
 VIS
 SCHRAUBE
 TORNILLO

Q.TY n.4

6




RONDELLA Ø6mm

WASHER Ø6mm
 RONDELLE Ø6mm
 SCHEIBE Ø6mm
 ARANDELA Ø6mm

Q.TY n.4

7



RONDELLA Ø6x18mm

WASHER Ø6x18mm
 RONDELLE Ø6x18mm
 SCHEIBE Ø6x18mm
 ARANDELA Ø6x18mm

Q.TY n.4

8




COPRIFORO Z621

BOLT CAP
 CACHE TROU
 STOPLOCK
 TAPA AGUJERO

Q.TY n.6

9



DADO A.B. M6

BOLT M6
 ECROU M6
 MUTTER M6
 TUERCA M6

Q.TY n.4

